

APPLICATION NOTE

Using IOS FIFO Feature for Sensor Hub

A-SOCAP3-ANGA04EN v1.2



Legal Information and Disclaimers

AMBIQ MICRO INTENDS FOR THE CONTENT CONTAINED IN THE DOCUMENT TO BE ACCURATE AND RELIABLE. THIS CONTENT MAY, HOWEVER, CONTAIN TECHNICAL INACCURACIES, TYPOGRAPHICAL ERRORS OR OTHER MISTAKES. AMBIQ MICRO MAY MAKE CORRECTIONS OR OTHER CHANGES TO THIS CONTENT AT ANY TIME. AMBIQ MICRO AND ITS SUPPLIERS RESERVE THE RIGHT TO MAKE CORRECTIONS, MODIFICATIONS, ENHANCEMENTS, IMPROVEMENTS AND OTHER CHANGES TO ITS PRODUCTS, PROGRAMS AND SERVICES AT ANY TIME OR TO DISCONTINUE ANY PRODUCTS, PROGRAMS, OR SERVICES WITHOUT NOTICE.

THE CONTENT IN THIS DOCUMENT IS PROVIDED "AS IS". AMBIQ MICRO AND ITS RESPECTIVE SUPPLIERS MAKE NO REPRESENTATIONS ABOUT THE SUITABILITY OF THIS CONTENT FOR ANY PURPOSE AND DISCLAIM ALL WARRANTIES AND CONDITIONS WITH REGARD TO THIS CONTENT, INCLUDING BUT NOT LIMITED TO, ALL IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHT.

AMBIQ MICRO DOES NOT WARRANT OR REPRESENT THAT ANY LICENSE, EITHER EXPRESS OR IMPLIED, IS GRANTED UNDER ANY PATENT RIGHT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT OF AMBIQ MICRO COVERING OR RELATING TO THIS CONTENT OR ANY COMBINATION, MACHINE, OR PROCESS TO WHICH THIS CONTENT RELATE OR WITH WHICH THIS CONTENT MAY BE USED.

USE OF THE INFORMATION IN THIS DOCUMENT MAY REQUIRE A LICENSE FROM A THIRD PARTY UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF THAT THIRD PARTY, OR A LICENSE FROM AMBIQ MICRO UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF AMBIQ MICRO.

INFORMATION IN THIS DOCUMENT IS PROVIDED SOLELY TO ENABLE SYSTEM AND SOFTWARE IMPLEMENTERS TO USE AMBIQ MICRO PRODUCTS. THERE ARE NO EXPRESS OR IMPLIED COPYRIGHT LICENSES GRANTED HEREUNDER TO DESIGN OR FABRICATE ANY INTEGRATED CIRCUITS OR INTEGRATED CIRCUITS BASED ON THE INFORMATION IN THIS DOCUMENT. AMBIQ MICRO RESERVES THE RIGHT TO MAKE CHANGES WITHOUT FURTHER NOTICE TO ANY PRODUCTS HEREIN. AMBIQ MICRO MAKES NO WARRANTY, REPRESENTATION OR GUARANTEE REGARDING THE SUITABILITY OF ITS PRODUCTS FOR ANY PARTICULAR PURPOSE, NOR DOES AMBIQ MICRO ASSUME ANY LIABILITY ARISING OUT OF THE APPLICATION OR USE OF ANY PRODUCT OR CIRCUIT, AND SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY, INCLUDING WITHOUT LIMITATION CONSEQUENTIAL OR INCIDENTAL DAMAGES. "TYPICAL" PARAMETERS WHICH MAY BE PROVIDED IN AMBIQ MICRO DATA SHEETS AND/OR SPECIFICATIONS CAN AND DO VARY IN DIFFERENT APPLICATIONS AND ACTUAL PERFORMANCE MAY VARY OVER TIME. ALL OPERATING PARAMETERS, INCLUDING "TYPICALS" MUST BE VALIDATED FOR EACH CUSTOMER APPLICATION BY CUSTOMER'S TECHNICAL EXPERTS. AMBIQ MICRO DOES NOT CONVEY ANY LICENSE UNDER NEITHER ITS PATENT RIGHTS NOR THE RIGHTS OF OTHERS. AMBIQ MICRO PRODUCTS ARE NOT DESIGNED, INTENDED, OR AUTHORIZED FOR USE AS COMPONENTS IN SYSTEMS INTENDED FOR SURGICAL IMPLANT INTO THE BODY, OR OTHER APPLICATIONS INTENDED TO SUPPORT OR SUSTAIN LIFE, OR FOR ANY OTHER APPLICATION IN WHICH THE FAILURE OF THE AMBIQ MICRO PRODUCT COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR. SHOULD BUYER PURCHASE OR USE AMBIQ MICRO PRODUCTS FOR ANY SUCH UNINTENDED OR UNAUTHORIZED APPLICATION, BUYER SHALL INDEMNIFY AND HOLD AMBIQ MICRO AND ITS OFFICERS, EMPLOYEES, SUBSIDIARIES, AFFILIATES, AND DISTRIBUTORS HARMLESS AGAINST ALL CLAIMS, COSTS, DAMAGES, AND EXPENSES, AND REASONABLE ATTORNEY FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PERSONAL INJURY OR DEATH ASSOCIATED WITH SUCH UNINTENDED OR UNAUTHORIZED USE, EVEN IF SUCH CLAIM ALLEGES THAT AMBIQ MICRO WAS NEGLIGENT REGARDING THE DESIGN OR MANUFACTURE OF THE PART.

Revision History

Revision	Date	Description
1.0	March 2017	Initial release
1.1	April 12, 2022	Updated template
1.2	January 3, 2023	Updated document part number

Reference Documents

Document ID	Description

Table of Contents

1. Introduction	5
2. Host and MCU Protocol	6
3. Using IOS FIFO Feature	7

SECTION

1

Introduction

Apollo/Apollo2 I²C/SPI Slave Module (IO Slave or IOS) can be used to efficiently implement a Sensor Hub application, which acts as a central aggregator for data from multiple discrete sensors, and provides a single interface for Host applications (e.g., a smartphone).

Apollo's IOS module has a built-in FIFO interface which can support accumulating up to 1,023 bytes of data, independent of when the Host transfers the data out. The FIFO is implemented partially in the hardware (up to 128 Bytes¹), with the overflow in the SRAM. At any point of time, the head of the queue is in the hardware FIFO, and the rest is stored in the SRAM.

The Hardware design of IOS allows for power efficient implementation of the FIFO. Read requests from Host are handled completely in the hardware, with the MCU involvement limited to replenishing the hardware FIFO (copying data from SRAM to hardware FIFO). The MCU is triggered by interrupts based on configurable hardware FIFO thresholds.

New data addition to the FIFO can work simultaneously with the Host reads. IOS provides FIFO visibility and control to the Host through the I²C/SPI interface by exposing special offsets in the IOS RAM, which can be accessed by the Host. Additionally, a direct access area can be provisioned in IOS for any out of band control exchange.

Since the FIFOCTR (which is the Host's view of the current FIFO Size available to read) is a multiple byte value, an explicit synchronization is needed between the Host and MCU to control access to updates to this value to ensure a consistent snapshot can be accessed by the Host.

An interrupt based synchronization mechanism is recommended for MCU to handshake the data transfer with the Host for optimized power efficiency. The Host can configure and enable explicit interface interrupts from MCU, which can be used to notify the Host of new data availability. For synchronization in the reverse direction, the Direct Access Area can be used by the Host to write messages for MCU, and a built-in interrupt mechanism (based on offset access) can be used to interrupt the MCU.

¹For efficient use by Software, one byte of hardware FIFO space is wasted to distinguish the Empty from Full condition.


SECTION

2

Host and MCU Protocol

Figure 2-1 depicts a recommended protocol for data exchange between MCU and Host during active sensor data accumulation, and the same is described in detail below.

Figure 2-1: Host and MCU Protocol



SECTION

3

Using IOS FIFO Feature

During initialization, Host enables an interrupt from IOS by configuring the **IOINTEN** field in **IOINTCTL** register for MCU by writing to offset 0x78. This allows the MCU to interrupt the Host by writing to **IOINTSET** field in **IOINTCTL** register in IOS.

When IOS has some data for Host, it implements a state machine, synchronizing with the Host.

1. MCU receives new Data from Sensor(s) in the Idle state.
2. MCU writes the data to the FIFO (using `am_hal_ios_fifo_write()`).
3. MCU informs the Host of new data availability:
 - a. MCU Updates the FIFOCTR to reflect the current FIFO size (using `am_hal_ios_update_fifoctr()`).
 - b. MCU interrupts the Host by writing to **IOINTSET** field in **IOINTCTL** register in IOS, to indicate new data availability (using `am_hal_ios_host_int_set()`).
MCU keeps accumulating any new data coming in the background (using `am_hal_ios_fifo_write()`).
4. Host receives interrupt from MCU
 - a. Host reads the interrupt status by reading at offset 0x79 to confirm new data availability.
 - b. Host clears the interrupt by writing to offset 0x7A.
5. Host reads the amount of available data to read (as indicated by **FIFOCTR**) by reading offset 0x7C/0x7D.
6. Host then reads the actual data by issuing one or more IO Read transactions on IOS FIFO through address 0x7F.
7. Host sends an acknowledgment message to IOS once it has finished reading a block of data initiated by IOS interrupt.
8. MCU is interrupted once the Host message is received (`am_ioslave_acc_isr()`)
MCU interrupts the Host again if it has more data for the Host to read (and the cycle repeats), or else it goes back to 'Idle' state waiting for new data from the sensor(s).



© 2023 Ambiq Micro, Inc. All rights reserved.

6500 River Place Boulevard, Building 7, Suite 200, Austin, TX 78730

www.ambiq.com

sales@ambiq.com

+1 (512) 879-2850

A-SOCAP3-ANGA04EN v1.2

January 2023